

1. Remove the tent from the bag. Place the tent in the center of the location. Expand the legs and stop at a whole arm's length.



2A. Grab the bottom of the scissor bar, lift it up and step backwards until the tent is fully extended. Be cautious not to get pinched by the frame (for 10x20 tent, see 2B).



2B. Grab the scissor bars that are connected to the middle leg, lift them up and step backwards until the tent is fully extended. Be cautious not to get pinched by the frame.



3. Push the auto slider up until it is locked. Repeat the same step on the other sides.



4. Pull the legs up to the desired heights. Use the push-pin to slide up and down to adjust the height. Repeat the same step on the other sides.



IMPORTANT INFORMATION

1. Always take down the tent in heavy winds.
2. Use mild soap (not detergent) and hand wash. Rinse with plenty of water. Hang dry.
3. Make sure the canopy is completely dry when storing.
4. The tent is NOT designed for extreme weather conditions. Do not leave the tent unattended.

HOW TO TAKE DOWN YOUR INSTANT CANOPY

1. Push the push-pin to lower the tent. Repeat the same step on the other sides.



2. Release the auto slider by pushing the push-pin and pulling it down. Repeat the same step on the other sides.



3. Grab the scissor bars, lift them up (shake them a little bit if you need to), and collapse the tent. Be cautious not to get pinched by the frame.

