






INSTRUCTION

CTF-SNK Series



If can't snap when dismantle the frame,Pls push the tube forwardly,then push again.

